

---

# NI-9860 and sbRIO-9860 Specifications

---

2024-06-27



# Contents

NI-9860 and sbRIO-9860 Specifications.....	3
--	---

# NI-9860 and sbRIO-9860 Specifications

## Module Version

These specifications apply to NI-9860 modules with part number 157128x-04L (where x represents any letter) and to sbRIO-9860 modules.

## Definitions

**Warranted** specifications describe the performance of a model under stated operating conditions and are covered by the model warranty.

**Characteristics** describe values that are relevant to the use of the model under stated operating conditions but are not covered by the model warranty.

- **Typical** specifications describe the performance met by a majority of models.
- **Nominal** specifications describe an attribute that is based on design, conformance testing, or supplemental testing.

Specifications are **Typical** unless otherwise noted.

## Conditions

Specifications are valid for the range -40 °C to 55 °C unless otherwise noted.

### Related information:

- [Software Support for CompactRIO, CompactDAQ, Single-Board RIO, R Series, and EtherCAT](#)

## NI-XNET Host Port

Connector type	NI-XNET hardware selectable interface port
Port supported transceiver cable types	NI-XNET transceiver cables (CAN/LIN)



**Note** For more information about transceiver cables, refer to the transceiver cable operating instructions.

## Safety Voltages

Connect only voltages that are within the following limits:

V <sub>sup</sub> -to-COM	9 V DC to 30 V DC, 1.5 W maximum, Measurement Category I
Chassis ground-to-COM	30 V DC maximum, Measurement Category I

## Measurement Category I



**Warning** Do not connect the product to signals or use for measurements within Measurement Categories II, III, or IV, or for measurements on MAINS circuits or on circuits derived from Overvoltage Category II, III, or IV which may have transient overvoltages above what the product can withstand. The product must not be connected to circuits that have a maximum voltage above the continuous working voltage, relative to earth or to other channels, or this could damage and defeat the insulation. The product can only withstand transients up to the transient overvoltage rating without breakdown or damage to the insulation. An analysis of the working voltages, loop impedances, temporary overvoltages, and transient overvoltages in the system must be conducted prior to making measurements.



**Mise en garde** Ne pas connecter le produit à des signaux dans les catégories de mesure II, III ou IV et ne pas l'utiliser pour des mesures dans ces catégories, ou des mesures sur secteur ou sur des circuits dérivés de surtensions de catégorie II, III ou IV pouvant présenter des surtensions transitoires supérieures à ce que le produit peut supporter. Le produit ne doit pas être raccordé à des circuits ayant une tension maximale supérieure à la tension de fonctionnement continu, par rapport à la terre ou à d'autres voies, sous peine d'endommager et de compromettre l'isolation. Le produit peut tomber en panne et son isolation risque d'être endommagée si les tensions transitoires dépassent la surtension transitoire nominale. Une analyse des tensions de fonctionnement, des impédances de boucle, des surtensions temporaires et des surtensions transitoires dans le système doit être effectuée avant de procéder à des mesures.

Measurement Category I is for measurements performed on circuits not directly connected to the electrical distribution system referred to as **MAINS** voltage. MAINS is a hazardous live electrical supply system that powers equipment. This category is for measurements of voltages from specially protected secondary circuits. Such voltage measurements include signal levels, special equipment, limited-energy parts of equipment, circuits powered by regulated low-voltage sources, and electronics.



**Note** Measurement Categories CAT I and CAT O are equivalent. These test and measurement circuits are for other circuits not intended for direct connection to the MAINS building installations of Measurement Categories CAT II, CAT III, or CAT IV.

## Environmental Characteristics

Temperature	
Operating	-40 °C to 55 °C
Storage	-40 °C to 85 °C

<b>Humidity</b>	
Operating	10% RH to 90% RH, noncondensing
Storage	5% RH to 95% RH, noncondensing
<b>Ingress protection</b>	
NI-9860	IP30
NI-9860 with power and transceiver cables attached	IP40
Pollution Degree	2
Maximum altitude	5,000 m
<b>Shock and Vibration</b>	
<b>Operating vibration</b>	
Random	5 g RMS, 10 Hz to 500 Hz
Sinusoidal	5 g, 10 Hz to 500 Hz
Operating shock	30 g, 11 ms half sine; 50 g, 3 ms half sine; 18 shocks at 6 orientations

To meet these shock and vibration specifications, you must panel mount the system.

## Power Requirements

<b>Power consumption from chassis</b>
---------------------------------------

Active mode	1 W maximum
Sleep mode	5 mW maximum
<b>External Power Supply<sup>1</sup> (V<sub>sup</sub>)</b>	
Voltage input range	9 V DC to 30 V DC (measured at the NI-9860 power connector)
Power consumption	1.5 W maximum (active mode)
Total thermal dissipation on module	1.2 W maximum (active mode)

## Physical Characteristics

Dimensions	Visit <a href="https://ni.com/dimensions">ni.com/dimensions</a> and search by module number.
Weight	Approx. 144 g (5.0 oz)

1. Required to power NI-XNET Transceiver Cables.